



MASERGY



USER GUIDE | CLOUD COMMUNICATIONS



MASERGY

Cisco 8800 Series Multiplatform IP Phones Quick Start Guide

Document Version 1.0
May 2018



Masergy Cisco 8800 Series Multiplatform IP Phone









Your Phone

1. Incoming call or voicemail indicator
2. Camera (Cisco IP Phone 8845 and 8865)
3. Line keys, SCA, and BLF buttons
4. Softkeys
5. Back, Navigation cluster, and Release
6. Hold, Transfer, and Conference
7. Headset, Speakerphone, and Mute
8. Voicemail, Menu, and Directory
9. Volume

Line Key Buttons

Use the line keys to access the assigned lines.

Buttons illuminate to indicate status:

-  Green, steady: Line is idle
-  Red, steady: Line in use
-  Red, slow flashing: Line on hold
-  Red, fast flashing: Incoming call
-  Amber, steady: Line unregistered
-  Amber, flashing: Line registering


Place a Call

Enter a number and pick up the handset.


Answer a Call

Press the flashing red line button to answer the non-shared line. If line is shared must select “answer” softkey.


Put a Call on Hold

1. Press Hold 
2. To resume a call from hold, press Hold again.


View Your Recent Calls

1. Press Menu 
2. Scroll and select Recents.
3. Select a line to view.

Transfer a Call to Another Person


1. From a call that is not on hold, press Transfer 
2. Enter the other person’s phone number.
3. Press Transfer again (before or after the party answers).

Add Another Person to a Call


1. From an active call, press Conference 
2. Enter the number you want to join and press Dial.
3. Once the call is connected, press Conference again.




Place a Call with a Headset

1. Plug in a headset.
2. Enter a number using the keypad.
3. Press Headset 

Place a Call with the Speakerphone

1. Enter a number using the keypad.
2. Press Speakerphone 

Mute Your Audio


1. Press Mute 
2. Press Mute again to turn mute off.

Stop Your Video

(Cisco IP Phone 8845 and 8865)

1. Turn the camera shutter counterclockwise to stop your video.
2. Turn the camera shutter clockwise to start your video.



Listen to Voice Messages

Press Messages  and follow the voice prompts. To check messages for a specific line, press the line button first.



Forward All Calls

1. Select the right side softkey with Dots to locate the Forward and press this softkey.
2. Dial the number that you want to forward to followed by "#", you will hear confirmation tone.
3. When you return, select the softkey with Dots to locate the Clr Fwd softkey and press this softkey to end call forwarding.


Adjust the Volume in a Call

Press Volume   up or down to adjust the handset, headset, or speakerphone volume when the phone is in use.


Adjust the Ringtone Volume

Press Volume   up or down to adjust the ringer volume when the phone is not in use.

Change Ringtone

1. Press Menu 
2. Select User Preferences.
3. Select Audio Preferences.
4. Select Extension(line key).
5. Use Navigation Cluster right arrow to go to the list of ringtones and press Play to hear a sample.
6. After choosing your ringtone using the "select" softkey and then hit the Set softkey to save the new ringtone.

Adjust the Screen Brightness

1. Press Menu 
2. Select User Preferences.
3. Select Screen Preferences
4. Select Display Brightness using Navigation Cluster.
5. Press the Navigation Cluster left to decrease, right to increase, the brightness.
6. Press Save

For further information on other Masergy supported telephones please visit the Masergy [IP Phones](#) webpage.